

Warrior Products, Inc.

HALF DOOR WINDSHIELD BRACKETS

INSTALLATION INSTRUCTIONS

WAR 1520

Congratulations on your purchase of a quality Warrior Products part. Please read the instruction carefully before beginning.

1. Your diamond plate half doors must be mounted onto your Jeep in order to install the brackets properly. The top window portion of your soft top door must be positioned as you want it to fit above your aluminum half door.
2. With the window in the proper position, slide shorter mounting bracket marked #1 onto the forward window mounting post. The other short bracket with no marking is the middle bracket. Slide this bracket onto the middle post. With the bracket flanges pointing towards the rear of the vehicle, mark through the bolt holes onto the half door for drilling.
3. Follow the same procedure for the rear bracket that fits adjacent to the door handle, only with the bracket flange pointing towards the front of the vehicle.
4. Drill six 1/4" holes where you have made your marks and install the brackets using the 1/4" x 3/4" bolts provided. The bolts should be installed with the bolt heads on the outside of the door. Be sure the bolts are tightened securely.
5. Slide your soft top window mounting posts into the brackets and test for proper fit.
6. Congratulations! You have successfully mounted your new brackets. Be sure to review the enclosed catalog for other quality Warrior Products.

PARTS: 2- SHORT BRACKETS, WITH #1 MARKING
2- SHORT BRACKETS, NO MARKING
2- LONG BRACKETS
12- 1/4" X 3/4" BOLTS WITH NUTS AND WASHERS

WARRIOR PRODUCTS INC.

11100 SW INDUSTRIAL WAY
TUALATIN OREGON 97062
(503) 691-8915

"Your Knight in Shining Armor!"