


Warrior Products, Inc.

SPRING OVER CONVERSION KIT
INSTALLATION INSTRUCTIONS

WAR 4600, 4605, 4610, 4615

YOUR KIT SHOULD CONTAIN THE FOLLOWING PARTS:

- 
- 2 UNIVERSAL SHOCK MOUNTS
 - 2 SPRING PERCHES
 - 2 P-19 SHOCKBOLTS
 - 2 UNIVERSAL U-BOLT PLATES
 - 2 COUPLER NUTS

Installation Instructions are **not** provided due to the multitude of variables that come into play when performing a spring over conversion. If you are not a qualified mechanic, or do not have access to necessary expertise, you should not attempt this conversion. You may need the assistance of your local 4X4 installer or service center.

.....
“Your Knight in Shining Armor!”