

# Warrior Products, Inc.

## **“TORQUE BARZ”**

### WAR630 INSTALLATION INSTRUCTIONS

- 1.) Raise rear of vehicle and securely place on jack stands. Remove rear tires for ease of installation.
- 2.) Install bushings and sleeves into torque barz, install mounting brackets onto torque barz using supplied hardware.
- 3.) Hold torque barz and brackets up to frame and axle as illustrated in picture to get an idea of mounting location, mark as needed.
- 4.) Axle bracket is to be welded to axle housing, while the frame bracket can be welded or bolted in place. Install frame bracket first. (If welding bracket be sure to remove torque barz first, so the heat won't melt bushings.) Once cool reinstall torque barz and axle bracket. Hold axle bracket in place on axle housing. Give bracket ½" –1" of clearance to u-bolt. Remove torque barz and weld bracket.
- 5.) Once everything is cool, touch up paint and reinstall torque barz.
- 6.) Reinstall tires and place vehicle on ground. Now a 7/16" hole can be drilled through barz for the locking pin. Drill hole 1" from open end of the larger bar, all the way through both barz.
- 7.) Install pins.

*“Your Knight in Shining Armor!”*