



Protecting Your Adventure Lifestyle

Warrior Products, Inc.
16850 SW Upper Boones Ferry Rd
Ste. A
Durham, OR 97224
Phone (888) 220-6861
Fax (503) 692-0364
sales@warriorproducts.com

SHOVEL & AXE MOUNT

INSTALLATION INSTRUCTIONS

WAR 841

NOTE: Please read all instructions before starting installation.

1. PARTS BREAK DOWN
2-SMALL BRACKETS
4-LARGE BRACKETS
4-7/16" NUTS AND WASHER
2-1/2" WING NUTS
2. TAKE THE LARGE BRACKET WITH BOLTS WELDED TO IT AND PLACE THE BOLTS BETWEEN THE BASKET TOP AND BOTTOM TUBES.
3. THEN TAKE THE SMALL BRACKET WITH TWO HOLES AND SLIP OVER THE BOLTS FROM THE INSIDE OF THE BASKET. PLACE THE 7/16" WASHERS OVER BOLTS AND THEN THE LOCK NUTS AND TIGHTEN INTO PLACE AS DESIRED. SPACE THE OTHER LARGE BRACKET WITH BOLTS APPROXIMATELY 18" APART AND REPEAT STEP 1 AND 2.
4. NOW TAKE THE OTHER LARGE BRACKET WITH ONE HOLE AND SLIP IT OVER THE BOLT AND START THE 1/2" WING NUT. THEN REPEAT ON OTHER MOUNT. SLIP THE SHOVEL AND AXE INTO TOP AND BOTTOM CLAMPS AND TIGHTEN WING NUTS.
5. CHECK WING NUTS AFTER EVERY OUTING OFF ROAD.

If you need further assistance installing your product, please contact us by email at techsupport@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS