



Protecting Your Adventure Lifestyle

Warrior Products, Inc.  
16850 SW Upper Boones Ferry Rd  
Ste. A  
Durham, OR 97224  
Phone (888) 220-6861  
Fax (503) 692-0364  
sales@warriorproducts.com

---

**ALUMINUM HALF DOORS**  
INSTALLATION INSTRUCTIONS  
**WAR 914DOOR**  
TOYOTA FJ-40 LANDCRUISER

**Read all instructions before proceeding.**

**NOTE: You will need to purchase a Bestop Paddle Handle #245-46 and follow their instruction for its installation. Modify the striker pin as needed.**

1. On the inside of each door, install foam molding per Diagram "A".
2. Install Paddle Handle and modify striker as needed.
3. Hang door on your vehicle and check for proper fit. Close door slowly onto paddle striker being sure that the paddle and striker line up correctly. You may need to "tweak" the hinges to get a perfect fit.

**Enjoy your new Warrior half doors!**

If you need further assistance installing your product, please contact us by email at [techsupport@warriorproducts.com](mailto:techsupport@warriorproducts.com) or call us at (888) 220-6861.

**THANK YOU FOR PURCHASING WARRIOR PRODUCTS**