

.....

# Warrior Products, Inc.

## INSTALLATION INSTRUCTIONS WAR 1010

Insert double bolt strap through access hole in end of the vehicle frame. Bolts will drop thru existing slot and large round hole.

Position receiver on frame with bolts protruding down through forward two slotted holes in the receiver flange. While pushing receiver forward, to allow adequate clearance from the bumper, mark remaining two holes to be drilled. (Help will be required to hold receiver in place).

Drill rear two 1/2" mounting holes as marked in previous step. CAUTION Always use eye protection when operating a drill. (Watch for any wires).

Insert remaining 1/2" x 2" bolts with 1/4" spacer on bolts through access hole in the end of frame and drop in the newly drilled hole.

Attach receiver. Position 3/8" spacers between receiver flange and frame. Secure with six each 1/2" HD flatwasher, 1/2" lock-washer and 1/2" hex nut.

**Do Not Exceed Vehicle Manufacturers  
Recommended Towing Capacity!**

*"Your Knight in Shining Armor!"*

.....