

.....

Warrior Products, Inc.

INSTALLATION INSTRUCTIONS WAR 1030 & 1031

1. Remove factory bumperettes from both rear frame horns.
 2. All eight (8) mounting holes will have to be enlarged to accept 1/2" bolts which are supplied in the installation kit. If you are going to reinstall your bumperettes, drill these to accept the bolts.
 3. The eight washers, with two (2) holes, must be installed with each pair of bolts. One in front of the hitch, four places, and one behind the frame, four places.
 4. The outside washer can go either on top of the bumperette or behind, but must be on the outside of the hitch. The hitch must be secured next to the frame.
 5. Tighten all mounting bolts to 75ft.lbs. with a torque wrench.
- Load Capacity 2,500 – 5,500 lbs.



**Do Not Exceed Vehicle Manufacturers
Recommended Towing Capacity!**

“Your Knight in Shining Armor!”

.....