

.....

Warrior Products, Inc.

INSTALLATION INSTRUCTIONS

WAR 1034 & 1038

Some Applications May Vary

Prepare vehicle frame. Remove spare tire and rear bolt of spare tire holder. Clean away any mud and most of the undercoating, if present.

Position hitch on frame (Help may be required to hold receiver in position while marking mounting holes).

- A. Position receiver so that receiver tube extends approx. even with end of vehicle.
- B. Optional 3/8" spacers must be used between receiver flange and frame to clear rivets.
- C. Using receiver as template, mark the (6) holes to be drilled for mounting of receiver.

Drill mounting holes – Caution, always use eye protection when operating a drill.

- A. Check frame of vehicle to be sure no wires or hoses will be damaged while drilling the mounting holes.
- B. Drill 1/2" mounting holes (6) places. Attach receiver to vehicle frame.
- C. Use spacers as necessary to level receiver, or to space receiver below any frame rivets. 1/4" mounting blocks must be used inside frame.
- D. Mount receiver to frame with (6) sets of hardware as shown.

Reinstall spare tire and mounting bracket if required. Use tire mounting bracket included in the hardware kit to reinstall spare tire holder if necessary.

Tighten all mounting bolts to 75 Ft./Lbs. using a torque wrench.

Do not exceed Vehicle Manufacturers Recommended Towing Capacity!

(Load Capacity –5,000 to 10,000 lbs)

“Your Knight in Shining Armor!”

.....