

.....

# Warrior Products, Inc.

## INSTALLATION INSTRUCTIONS WAR 1041

1. Remove rear bumper from frame, along with bumper brackets.
2. Position receiver against bottom of frame to line up with existing holes.  
  
Using bolts supplied in installation kit, install 1/2" bolt in bottom of frame to hold hitch in place.
3. Modify bumper brackets to reinstall on outside of hitch. Some cutting may be required. Re-use bolts that were removed when bumper brackets were removed in step #1.
4. Place bumper back onto bumper brackets. Sometimes a slight modification is required for bumper clearance.
5. Tighten all mounting bolts to 65ft.lbs. with a torque wrench. Check bolts for torque after your first use.

\*Load Capacity 3,500 – 5,000 lbs.

**Do not exceed Vehicle Manufacturers  
Recommended Towing Capacity!**

.....

*"Your Knight in Shining Armor!"*