

.....

Warrior Products, Inc.

INSTALLATION INSTRUCTIONS WAR 1043 -2 FOR TRUCKS WITH LONG BED OR EXTENDED CABS WITH REAR BUMPER

PREPARE VEHICLE FRAME

1. Vehicle frame where hitch will be mounted must be cleaned before installing hitch.
2. Remove bumper from the frame with the bumper brackets left on the bumper. Disconnect all the wiring before final removal of bumper.

INSTALLING HITCH ASSEMBLY

1. Place reinforcing brackets into their respective frame channels. The square end of the brackets must be even with the end of the frame and the tapered end will point towards the front of the vehicle.
2. Install the receiver assembly against the bottom of the frame. It should be positioned so that the rear set of holes will be off the end of vehicle frame. Temporarily attach hitch to frame using one bolt per side at existing hole.
3. Reposition bumper brackets against outside of each frame member and bolt all parts to vehicle using bolts supplied with hitch.
4. There will be two (2) remaining holes in the hitch that do not have bolts in them. Use the hitch as a drilling guide, drill two (2) 1/2" holes through the bottom of the frame. Bolt parts together.

CAUTION: Always use eye protection when operating a drill motor.

5. Bolt parts to frame as illustrated. Be sure that a spacer plate is used under frame at the most forward mounting hole.
6. Tighten all mounting bolts using a Torque Wrench to 75 ft. – lbs.

**Do not exceed Vehicle Manufacturers
Recommended Towing Capacity!**

.....

“Your Knight in Shining Armor!”