

.....

Warrior Products, Inc.

INSTALLATION INSTRUCTIONS **WAR 1043 -1** FOR TRUCKS WITH SHORT BED OR TRUCKS WITH LONG BED AND NO REAR BUMPER

PREPARE VEHICLE FRAME

1. Vehicle frame where hitch will be mounted must be cleaned before installing hitch.

INSTALLING HITCH ASSEMBLY

1. Place reinforcing brackets into their respective frame channels. The square end of the brackets must be even with the end of the frame and the tapered end will point towards the front of the vehicle.
2. Install the receiver assembly against the bottom of the frame. It should be positioned so that the rear set of holes line up with existing holes in vehicle frame. Bolt the receiver hitch together on bottom of frame and on the side.
3. There will be two (2) remaining holes in the hitch that do not have bolts in them. Use the hitch as a drilling guide, drill two (2) ½” holes through the bottom of the frame. Bolt parts together.

CAUTION: Always use eye protection when operating a drill motor.

4. Tighten all mounting bolts using a Torque Wrench to 75 ft. – lbs.

**Do not exceed Vehicle Manufacturers
Recommended Towing Capacity!**

.....

“Your Knight in Shining Armor!”