

.....

# Warrior Products, Inc.

## INSTALLATION INSTRUCTIONS WAR 1046

Remove rear bumper and brackets from vehicle. Remove bolts and clip nuts from frame and discard.

Place ½” x 2” bolt and ¼” spacer into each of the six existing holes in frame, on SWB there are only four existing holes.

Raise receiver into position. Position center slots over the bolts in the frame. Use the two large cutouts to clear rivets. Secure the two forward bolts only (one on each side).

Raise the bumper back into position. Bumper bracket bolts may need to be reversed or loosened temporarily to aid in re-installing bumper. Secure remaining bolts with HD flatwasher, lockwasher, and hex nut. Tighten any bumper brackets bolts.

On SWB models, the forward tow holes must be drilled and secured with hardware provided. CAUTION- Always use eye protection when operating a drill.

Tighten all mounting bolts to 75 ft./lbs with torque wrench.

\*Load Capacity 3,500 – 5,000 lbs.

**Do not exceed Vehicle Manufacturers  
Recommended Towing Capacity!**

.....

*“Your Knight in Shining Armor!”*