

.....

Warrior Products, Inc.

INSTALLATION INSTRUCTIONS WAR 1049

Insert a ¼” spacer and a ½” x 2” bolt in hole that is about four inches away from the end of the vehicle frame. Insert spacer and bolt on both sides of frame.

Raise brackets into place, use large cutouts to clear body mounts and tie downs. Use the second rear hole in bracket to temporarily hold hitch to frame on each side. Temporarily tighten all bolts after centering hitch.

Mark and drill the three ½” mounting holes on each side. CAUTION- Always use eye protection when operating a drill.

Remove the hitch. Carefully insert a 3/8” U-Bolt in the two forward holes, on each side. In the rear holes, insert a ½” x 2” bolt and ¼” spacer.

Raise hitch back into position, be careful not to push U-Bolts into the boxed frame. Secure each bolt with the correct size HD flatwasher, lockwasher and hex nut.

Raise hitch center section back into position and secure with three ½” x 1½” bolts, lockwasher and hex nuts per side.

*Load Capacity – 3,500 – 5,000 lbs

**Do not exceed Vehicle Manufacturers
Recommended Towing Capacity!**

.....

“Your Knight in Shining Armor!”