

.....

# Warrior Products, Inc.

## INSTALLATION INSTRUCTIONS WAR 1052

**Note: On some '98 & up models, the bumper stiffener plate may have to be modified or removed for clearance.**

1. Install hitch hangers one side at a time.
2. Remove the 14mm double bolt strap from each side, one at a time.  
CAUTION – These bolts hold the bumper on. Throw away bolts save the four nuts, they will be used later.
3. Install a 14mm bolt from the inside of the frame pointing out through the bumper bracket. Lock a ¼” spacer in the two round and one slotted holes in the frame.
4. Install the 3” x 4” spacer on each side of the outside frame over the slotted hole, this keeps the hitch in line with the frame.
5. Install the hitch hanger over the three 14mm bolts from the outside of the frame and secure the two 14mm nuts, removed earlier, with a ¼” spacer and nut as provided.
6. Install hitch center section, using the six ½” bolts, locks and nuts as provided.
7. Re-level the bumper and hitch, tighten the six 14mm bolts. Also tighten the six ½” bolts.

\*Load Capacity 3,000 – 6,000 lbs.

**Do not exceed Vehicle Manufacturers  
Recommended Towing Capacity!**

.....

*“Your Knight in Shining Armor!”*