

# Warrior Products, Inc.

## INSTALLATION INSTRUCTIONS WAR 1072

**1994 & UP S-10 PICKUP  
1994 & UP GMC S-15 PICKUP**

### PREPARE VEHICLE FRAME

1. Remove bumper and bumper brackets from vehicle. Be sure to twist the License plate lights from their sockets before completing removal.
2. Remove the frame attachment brackets from bumper.

### POSITION HITCH ON FRAME (Help may be required to hold Receiver in position).

1. The four holes on each side of the frame that will secure the receiver, need to be enlarged to 1/2". The furthest forward holes must be used.

### WHEN DRILLING MOUNTING HOLES – CAUTION- Always Use Proper Eye Protection When Operating A Drill Motor.

1. Raise the Receiver into place, then put bumper brackets in place and secure with the 1/2" x 2" bolts and large flatwashers supplied.
2. Tighten all mounting bolts using a torque wrench (1/2" to 75ft./lbs).
3. After Receiver and bumper brackets have been secured, use the 3/16" spacers between brackets on truck and bumper brackets to give proper spacing. Reuse existing bumper bolts removed earlier.

**Do not exceed Vehicle Manufacturers  
Recommended Towing Capacity!**

*"Your Knight in Shining Armor!"*