

.....

Warrior Products, Inc.

INSTALLATION INSTRUCTIONS WAR 1085

1. Remove bottom bumper bolts; threaded upwards into bottom of frame.
2. Slide hitch up alongside frame rails, reinstall bumper bolts through hitch into frame to hold hitch in place. **DO NOT TIGHTEN.**
3. With a 3/4" box end wrench, feed supplied 1/2" nut through hole in bottom of frame to upper hole, (step #3, figure #1) thread bolt into nut. **DO NOT TIGHTEN.**
4. Install nut and bolt (step #4, figure #1) into lower center hole. **DO NOT TIGHTEN.**
5. Tighten the 2 bolts on each side of frame to 65 ft/lbs. Tighten bottom bumper bolts to 65 ft/lbs.
6. Using a 1/2" drill bit, drill through frame using hitch hole as a guide (step #6, figure #1).
7. Install last bolts through drilled hole. Tighten to 65 ft/lbs.
8. After test drive re-torque all bolts.

*Load Capacity 2,500 – 5,500 lbs.

**Do not exceed Vehicle Manufacturers
Recommended Towing Capacity!**

.....

"Your Knight in Shining Armor!"