

Warrior, Inc.

## **OUTBACK RACK MOUNT KIT #43320** **INSTALLATION INSTRUCTIONS**

### **Read all instructions before proceeding.**

**Your vehicle must have the standard roof rack rails on both sides for this rack to mount properly. While the weight capacity of our cargo basket exceeds 400 lbs., with weight distributed evenly over the entire area of the rack, you should refer to your vehicle manual for the load capacity of the roof of your vehicle, and be guided by those constraints.**

1. Begin by removing the rear end caps from the rack rails on both sides of the roof. Then loosen and remove the locking tabs and any cross rail assemblies by sliding them to the rear until they are clear of the rails.
2. Install the basket mounting brackets by sliding three mounting brackets onto each rail with the flanges pointed to the inside. Position the brackets approximately to support the front, middle, and rear of the basket.
3. Lift basket in place on top of the brackets and then adjust the basket to center; forward to back, and left to right. The brackets should be positioned directly underneath the front, middle, and rear basket mounting plates.
4. Insert the 5/16" bolts and nuts provided, from the top. Tighten all nuts once you have confirmed that the basket is centered where you want it.
5. Install the 1/4" locking screws (two on each foot) inside of the rail. Insert the lock washer onto each screw first, followed by the flat washer. Tighten all screws.
6. Reinstall rear end caps removed in #1 above.
7. After a test drive, re-check tightness of all bolts and your done!

**Enjoy your new Outback Rack by Warrior!**

*"Your Knight in Shining Armor!"*