Warrior, Inc.
11100 SW Industrial Way
Tualatin, Oregon 97062
(503) 691-8915
(503) 692-0364 FAX
(888) 220-6861 Toll Free
wp@ warriorproducts.com

Warrior, Inc.

ADVENTURE RACK

INSTALLATION INSTRUCTIONS

WAR 833

1. Remove spare tire from the rear of the tailgate.

2. Remove the outer most bolt on the tailgate side of the hinge. (Both upper and lower) See figure "A"

3. Install passenger side leg over the tailgate hinge using the new longer bolts provided. Do not tighten the bolts at this time. (Bolt, lock washer, then flat washer)

4. On the latch side of the tailgate (see figure "A") drill 3/8" hole 1/2" from the side & 1/2" from the bottom of the tailgate.

5. Drill second 3/8" hole 1/2" from the side and 14 3/8" from the bottom of the tailgate. (see figure "A")

6. Install drivers side leg. Bolts are installed from inside of the tailgate pointing out. (see figure "B") Top bolt has a small flat washer next to bolt head (provided). Bottom bolt has large flat washer. Do not tighten bolts at this time.

7. Install basket on top of the legs.

8. Install lower brackets to bottom of legs using quick release pins. Mark drilling holes on the vehicle body where the bracket is positioned.

9. Remove brackets and drill 1/8" hole where marked. Install bracket using quick release pins before securing brackets with self tapping screws.

10. Tighten all bolts and check to be sure the **Rack** is securely attached to the rear of the vehicle. If you have bolted the rack only to your tailgate, a 50lb. Weight limit is advised. ENJOY YOUR NEW RACK!

"Your Knight in Shining Armor!"