Warrior Products, Inc.
11100 SW Industrial Way
Tualatin, Oregon 97062
(503) 691-8915
(503) 692-0364 FAX
(888) 220-6861 Toll Free
wp@ warriorproducts.com

Warrior Products, Inc.

INSTALLATION INSTRUCTIONS

WAR102

1. Jack up front end, remove wheel and secure on axle stands.

2. Place upper bracket against the front side of the coil spring tower, so that the top portion is above the tower and the bottom is leaning toward the engine.

3. Weld seam between spring tower and bracket.

4. Position shock in the top mount. Loosely position bottom bracket onto lower shock eye and extend shock 19 ½" (eye to eye). Mark the position for the lower bracket on the ridge of the radius bracket.

5. Remove lower bracket from shock. Weld bracket onto the ridge of the the radius bracket where it is marked. Water may be needed to cool area so "C" bushings don't melt.

6. Bolt on the shock at the top and bottom.

"Your Knight in Shining Armor!"